

Die Wand,  
die aus der Decke kommt  
... per Knopfdruck!

**LOSCHWAND®**  
classic  
GG/2-298

**Announcement-text LOSCHWAND® classic**  
**- G l a s s -**  
**Vertikal electric partition system**

**LOSCHWAND® classic GG / 2 - 298**

all-glass-design  
made from 2 pane laminated safety glass  
VSG from 2 x ESG 8 mm thick

Length: total length between vertical guide rails	.....mm
measurement of guide rail: 100 / 125 mm	
Length: LOSCHWAND® classic GG/2-298	max. 4100 mm
Height: Finished floor to finished ceiling	.....mm
Höhe: LOSCHWAND® classic GG/2-298	max. 3250 mm
Special height on inquiry	
Storage Space :in the false ceiling	.....mm
alternativ:	
below false ceiling	
"visible technology"	.....mm
Storage space height: LOSCHWAND® classic GG/2-298	min. 400 mm
Storage space depth: LOSCHWAND® classic GG/2-298	min. 1000 mm
Size of each glass-element:	Glass-strength: 17 mm
	Glass-height: 298 mm

**Operating mode:**

Fully automatic

**Technical description:**

The LOSCHWAND® classic GG/2-298 exists from a 2 pane of laminated safety glass, VSG from 2 x 8 mm ESG with 1,5 mm glass-foil, transparent. Colour foil, decor foil against extra charge. In closed position, there is a gap of approx. 3 mm between the elements. The elements are detained and guided by guide rails on each side and stored in a horizontal position in the magazine, normally located in the false ceiling. The drive and safety devises are incorporated in the magazine. An up down switch or key is required to operate the partition. The partition can not be lifted or pushed up when in closed position. The partition system has two safety devises. The safety system for the elements, which will engage, when the elements exceed a certain speed while closing, and a contact element below the lowest element in case there is something under the partition, while it is closing.

Colour of guide rails: acc. RAL-colour card

**Quotation::**

Delivery and assembly: \_\_\_\_\_

Extra charge for "visible technology" \_\_\_\_\_

Extra charge for colour foil, decor etc. \_\_\_\_\_

**Guarantee:**

5 years, except electric parts after VOL 6 months with conclusion of a maintenance-contract.

**Maintenance and examination:**

According the lawful regulations (ZH1/494), the partition-system must be test and serviced

Maintenance cost without spare parts per year: \_\_\_\_\_

**Maintenance-opening:**

Openings have to be installed for the yearly service and maintenance as per LOSCHWAND® specs.