

Die Wand,
die aus der Decke kommt
... per Knopfdruck !

LOSCHWAND®
HubWand

Announcement-text LOSCHWAND® HubWand
- G l a s s -
Vertikal electric partition system

LOSCHWAND® HubWand

all-glass-design
made from 2 pane laminated safety glass
VSG from 2 x ESG 8 or 10 mm thick

Length: total length between vertical guide railsmm
measurement of guide rail: 100 / 125 mm	
Length: LOSCHWAND® HubWand	unlimited
Special length on inquiry	
Height: Finished floor to finished ceilingmm
Height: LOSCHWAND® HubWand	max. 4000 mm
Special height on inquiry	
Storage Space :in the false ceilingmm
Storage space height: LOSCHWAND® HubWand	min. 300 mm
Storage space depth: LOSCHWAND® HubWand	min. 800 mm

Operating mode:

Fully automatic

Technical description:

The LOSCHWAND® HubWand exists from a 2 pane of laminated safety glass, VSG from 2 x 8 mm ESG with 1,5 mm glass-foil, transparent.

Colour foil, decor foil possible against extra charge.

In the closed position, there is a gap of approx. 3 mm between the elements

The elements are detained and guided by guide rails on each side.

The drive and safety devises are incorporated in the ceiling.

A up / down switch or key switch is required to operate the LOSCHWAND® HubWand.

The LOSCHWAND® HubWand system has two safety devises.

The safety system for the elements, which will engage,

when the elements exceed a certain speed while closing, and a pressure sensing strip below the lowest element in case there is something under the partition, while it is closing.

Pressure sensing strip will stop the closing movement of the LOSCHWAND® HubWand in case there is something under the glass.

Colour of guide rails: acc. RAL-colour card

Quotation::

Delivery and assembly: _____

Extra charge for "visible technology" _____

Extra charge for colour foil, decor etc. _____

Guarantee:

5 years, except electric parts after VOL 6 months with conclusion of a maintenance-contract.

Maintenance and examination:

According the lawful regulations (ZH1/494), the partition-system must be test and serviced

Maintenance cost without spare parts per year: _____

Maintenance-opening:

Openings have to be installed for the yearly service and maintenance as per LOSCHWAND® specs.